

APPLICATION TIPS



Graphic Application Tips 1: Clear INMOULD Graphic



Step 1

Rolling over tape and graphic to ensure good adhesion.

Step 2

Graphic appearance when flipped over.

Step 3

Hold application tape down on onto surface & peel back paper.

Step 4

Continue peeling paper back sharply at 180 to tape.

Step 5

Remove paper and discard. Graphic is now ready for application to mould surface.

ph: +64 6 833 6043

email: sales@psibrand.com

fax: +64 6 835 0693